


# HOME DECORATORS COLLECTION

BF-20193 HAMPTON BAY COLLECTION DOUBLE TILT-OUT HAMPERS

INV#26013

## ASSEMBLY INSTRUCTIONS













Made In China

















Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment. Count all parts and material hardware, then compare with parts list to be sure all parts are present. If any parts are missing or damaged, phone, fax, or mail to our Customer Service Department for efficient and speedy service. Please indicate the model number and code letter of part(s) needed.

IMPORTANT NOTE: Follow instructions listed below in proper sequence as numbered to assure fast, easy and correct assembly.



## PARTS LIST

<p><b>A</b></p>  <p>TOP PANEL-1PC</p>	<p><b>B</b></p>  <p>LEFT SIDE PANEL-1PC</p>	<p><b>B1</b></p>  <p>RIGHT SIDE PANEL-1PC</p>
<p><b>C</b></p>  <p>BAFFLE PANEL-1PC</p>	<p><b>D</b></p>  <p>BOTTOM PANEL-1PC</p>	<p><b>E</b></p>  <p>BACK PANELS-2PCS</p>
<p><b>F</b></p>  <p>(BUCKET) FRONT PANELS-2PCS</p>	<p><b>G</b></p>  <p>(BUCKET) SIDE PANELS-4PCS</p>	<p><b>H</b></p>  <p>(BUCKET) STICK PANELS-2PCS</p>
<p><b>H1</b></p>  <p>(BUCKET) BACK PANELS-2PCS</p>	<p><b>I</b></p>  <p>BASE PANELS-2PCS</p>	<p><b>J</b></p>  <p>STAND PANEL-1PC</p>

<p>K</p>  <p>CAM-LOCKS-12PCS</p>	<p>L</p>  <p>CAM-BOLTS-12PCS</p>	<p>M</p>  <p>FEET-4PCS</p>
<p>N</p>  <p>SCREWS-4PCS</p>	<p>O</p>  <p>KNOBS-2PCS</p>	<p>P</p>  <p>SCREWS-2PCS</p>
<p>Q</p>  <p>DOWELS-4PCS</p>	<p>R</p>  <p>HINGES-4PCS</p>	<p>S</p>  <p>SCREWS-14PCS</p>
<p>T</p>  <p>ALLEN WRENCH-1PC</p>	<p>U</p>  <p>CAM-TOOL-1PC</p>	<p>V</p>  <p>SCREWS-49PCS</p>
<p>W</p>  <p>BAGS-2PCS</p>	<p>X</p>  <p>REAR PANEL GUIDE-1PC</p>	




NOTE: THE SURFACE WITH THE STICKER IS THE BACK SIDE.

NOTE: • UPON OPENING, THOROUGHLY CLEAN ALL WOODS SURFACES TO REMOVE DUST AND DIRT THAT MAY HAVE SETTLED ONTO FINISH DURING SHIPMENT. IN ORDER TO PREVENT DAMAGE DURING ASSEMBLY, PLEASE ASSEMBLE THIS ITEM WITH AT LEAST TWO PEOPLE.




NOTE: TURN THE CAM-BOLT SCREWS UNTIL THEY ARE TIGHT, THE SHOULDER SHOULD BE AGAINST THE SURFACE OF THE PART.

## HOW TO USE THE CAM-TOOL




NOTE: • THE ARROWS ON THE HIDDEN CAM-LOCKS SHOULD POINT TO THE CAM-BOLTS




### 1) ASSEMBLE DIRTY CLOTHING BUCKET

- ① • ATTACH STICK PANEL (H) USING 6 SCREWS (V) AND ATTACH KNOB (O) USING SCREWS (P).
- ② • ATTACH SIDE PANEL (G) TO STICK PANEL (H) USING SCREWS (V).
- ③ • INSERT BASE PANEL (I) INTO THE SLOT IN THE PANEL (G/H).
- ④ • ATTACH BACK PANEL (H1) TO SIDE PANEL (G) USING SCREWS (V).




## 2) .ASSEMBLE THE FEET(M) .

- ATTACH 4 FEET(M) TO BOTTOM PANEL(D) USING SCREWS(N) .



## 3) .ASSEMBLE SIDE PANEL(B/B1) AND STAND PANEL(J) .


- INSERT 4 DOWELS(Q) INTO THE HOLES IN THE BAFFLE PANEL(C) AND SIDE PANEL(B/B1) .
- ROTATE THE 6 CAM-BOLTS(L) INTO THE HOLES IN THE BOTTOM PANEL(D) .
- PLACE CAM-BOLTS(L) INTO THE HOLES IN THE PANEL(B/B1/J) AND ATTACH USING 6 CAM-LOCK(K) .



#### 4) .ASSEMBLE TOP PANEL (A) .

- ROTATE THE 6 CAM-BOLTS(L) INTO THE HOLES IN THE TOP PANEL(A) .
- PLACE CAM-BOLTS(L) INTO THE HOLES IN THE PANEL(B/B1/J) AND ATTACH USING 6 CAM-LOCK(K) .
- ATTACH BAFFLE PANEL(C) USING SCREWS(V) IN THE PREDRILLED HOLES OF TOP PANEL(A) .


NOTE: THE METHOD IS FIT FOR ANOTHER BUCKET.



### 5) .ASSEMBLE DIRTY CLOTHING BUCKET.

- PUT THE BAG(W) INTO THE BUCKET.
- INSERT THE HINGES(R) INTO THE HOLES IN THE (BUCKET)FRONT PANEL(F).
- PLACE THE HINGE(R) BETWEEN INTO THE HOLES IN THE SIDE/STAND PANEL(B/B1/J).





#### 6) .ASSEMBLE THE BACK PANEL(E) .

- INSERT THE BACK PANEL(E) INTO THE SLOT IN THE REAR PANEL GUIDE(X) .
- ATTACH THE BACK PANEL(E) AND REAR PANEL GUIDE(X) USING SCREWS(S/V) .